



# **Recommendations for Use, Protection and Cleaning of MicroQuarz® Floors**

## **1. USAGE RECOMMENDATIONS**

**MicroQuarz®** flooring is resistant to foot traffic, flexible and seamless—ideal for homes, commercial spaces and high-traffic areas.

Although it offers high mechanical strength, it is important to follow these guidelines to preserve its condition:

- Do not drag furniture or heavy objects directly across the surface.
- Use protective pads under chairs, tables, and mobile furniture with hard tips or concentrated pressure points. Avoid excessive weight on small or sharp surfaces.
- Avoid using unprotected hard plastic wheels: soft rubber wheels or protective mats are recommended in office areas.

## **2. CLEANING & MAINTENANCE PROTOCOL**



### **>> DAILY CLEANING**

- Use water with a neutral detergent (pH between 6 and 8).
- Clean using a mop, microfiber cloth, or soft scrubbing machine—this last one is especially recommended for large areas.



### **>> ALWAYS AVOID**

- Bleach, ammonia, hydrochloric acid, alcohol, or abrasive products.
- Hard brushes, metal scourers, or abrasive pads..

**For stubborn stains, heavy dirt, or deeper daily cleaning:**

- Use FloorNet, an approved product by Ecoresinas.



### **>> VARNISH MAINTENANCE**

- No re-varnishing is required in residential settings if maintained properly.
- For commercial or high-traffic floors, we recommend reapplying Finish W TRP RADIANT. The frequency of reapplication depends on the intensity of commercial activity.



### 3. PROTOCOL FOR STUBBORN DIRT

**Recommended Product: FloorNet**

**Recommended Product: FloorNet**

#### STEP-BY-STEP

<b>1 – Preparing the mixture (for intensive use)</b>	<p>Dilute 1 part FloorNet in 5 parts water for deep cleaning.</p> <p>(Example: 200 ml of FloorNet per liter of water).</p> <p>This concentration can be increased to 1 part FloorNet and 2 parts water if there's embedded dirt.</p>
<b>2 – Apply directly on the affected area</b>	<p>Apply the mixture generously using a microfiber mop.</p> <p>You can also use a manual sprayer for localized areas.</p>
<b>3 – Let it work</b>	<p>Let it sit for 3 to 5 minutes on the dirt.</p> <p>Do not let it dry completely on the surface.</p>
<b>4 – Gently scrub</b>	<p>Use a soft sponge, soft-bristle brush, or white pad (if using a machine).</p> <p>Scrub in circular motions until the stain is removed.</p>
<b>5 – Rinse with clean water</b>	<p>Remove the product with a clean damp cloth or a well-wrung mop.</p> <p>If needed, rinse again to ensure no cleaner residue remains.</p>
<b>6 – Let it dry</b>	<p>Allow the area to air dry without covering or walking on it until completely dry.</p>

**Note:** If dirt remains after the treatment has been applied, the process can be repeated following the same instructions.

# ecoresinas

MINERAL COATINGS

C/Reina Elionor 25 - 27, 08205 Sabadell (Barcelona) | T. (+34) 977 079 111 • [comunicaciones@ecoresinas.com](mailto:comunicaciones@ecoresinas.com)

[www.ecoresinas.com](http://www.ecoresinas.com)



@ecoresinas