



Use, Protection and Cleaning Guidelines for MicroQuarz® Floors

1. USE RECOMMENDATIONS

MicroQuarz® applied to floors is resistant to foot traffic, flexible and seamless, ideal for homes, commercial spaces and high-use areas.

Although it has high mechanical resistance, it is important to follow these guidelines to preserve its condition.

Protection against furniture legs and point loads

To avoid marks, imprints or localized deformations, it is recommended to:

Place suitable protectors on the legs of chairs, tables, sofas, furniture, shelves, appliances and other heavy items.

Avoid heavy furniture resting directly on very small contact points, rigid wheels or narrow metal legs. It is recommended to increase the contact surface area using protective felt pads, rigid bases or load-spreading plates.

For furniture with wheels, use soft wheels or place bases/protectors that better distribute the load.

Do not drag heavy furniture or objects across the surface. Lift them, or protect the floor along the path before moving them.

Periodically check the condition of protectors, as they can accumulate abrasive particles or harden over time.

These recommendations help preserve the appearance of the floor and reduce the risk of visible marks caused by concentrated loads.



2. CLEANING AND MAINTENANCE PROTOCOL



DAILY CLEANING

- Use water with neutral detergent (pH between 6 and 8).
- Clean with a mop, microfiber mop or floor scrubber fitted with a soft pad, recommended for larger areas.



ALWAYS AVOID

- Bleach, ammonia, hydrochloric acid, alcohol or abrasive products.
- Hard brushes, metal scouring pads or abrasive discs.



For persistent stains, heavy soiling or intensive cleaning: Use FloorNet, an Ecoresinas-approved product.



PROTECTIVE FINISH MAINTENANCE

- No recoating is required in homes if the floor is properly cared for.
- For commercial or high-traffic floors, recoating with Finish W TRP RADIANT is recommended. The recoating interval will depend on how often the floor is used and the level of traffic.

3. CLEANING PROTOCOL FOR STUBBORN DIRT

Recommended Product: **FloorNet**.
Technical cleaner approved by Ecoresinas.



STEP BY STEP

1 - Preparing the mixture for intensive cleaning	Dilute 1 part FloorNet in 5 parts water for deep cleaning. <i>(Example: 200 ml of FloorNet per liter of water.)</i> This concentration can be increased to a stronger dilution of 1 part FloorNet to 2 parts water if embedded dirt requires it.
2 - Direct application on the affected area	Apply the mixture generously with a microfiber mop. A manual spray bottle may also be used to spray directly onto localized areas.
3 - Leave to work	Allow the product to work on the dirt for 3 to 5 minutes. Do not allow it to dry completely on the surface.
4 - Scrub gently	Use a soft sponge, a soft-bristle brush or a white cleaning pad if using a machine. Work in circular motions until the stain is removed.
5 - Rinse with clean water	Remove the product with a clean damp cloth or a well-wrung mop. If necessary, rinse again to make sure no cleaner residue remains.
6 - Drying	Allow the area to air dry without covering it or walking on it until it is completely dry.

Note: If dirt remains after treatment, the process can be repeated following the same instructions.

ecoresinas

MINERAL COATINGS

C/Reina Elionor 25, 08205 Sabadell (Barcelona) • (+34) 977 079 111 • comunicaciones@ecoresinas.com

www.ecoresinas.com



@ecoresinas